

# Provincial Toilet Replacement Rebate Program

## How to calculate the flush volume of the toilet you are replacing:

To make sure that your toilet is eligible to be replaced, check the back of the bowl for the flush volume stamp. The flush volume could also be located on a tank label or on the flush valve.

If you cannot see the flush volume information, you can also calculate the volume by multiplying its length, width and depth (from the fill line of the tank).

Example:

Length 33 cm x Width 19 cm x Depth 22 cm = 13794 cm<sup>3</sup>

This would equal 13794 ml, or a flush volume of 13.794 litres.

Note: one cubic centimeter (cm<sup>3</sup>) is equal to a cube of 1 centimetre on a side. One litre equals 1,000 cm<sup>3</sup> or a cube of ten centimetres on a side.